



NORDdiffuser

DJM Installation Manual


1. Installation to round duct



2. Installation to wall inserted round duct




3. Installation to square duct




4. Maintenance

4.1 With round duct



4.2 With wall inserted round duct or square duct





ETS NORD AS

Address: Peterburi tee 53
11415 Tallinn
Estonia

Phone: +372 680 7360
info@etsnord.ee
www.etsnord.ee

ETS NORD Finland

Address: Pakkasraitti 4
04360 Tuusula
Finland

Phone: +358 40 184 2842
info@etsnord.fi
www.etsnord.fi

ETS NORD Sweden

Address: Järsjögatan 7
692 35 Kumla
Sweden

Phone: +46 19 554 20 50

Address: Pinjegatan 5
213 63 Malmö
Sweden

Phone: +46 40 94 68 70

Address: Förrådsvägen 5
151 58 Södertälje
Sweden

Phone: +46 8 550 301 40

info@etsnord.se
www.etsnord.se

ETS NORD International

info@etsnord.com
www.etsnord.com

A large, stylized graphic on the left side of the page, consisting of several overlapping, concentric circular shapes in shades of gray, resembling a stylized eye or a lens.

Let's move the air together!