





NORDfire

CFDM/CFDM-V Installation Manual


1. CFDM/CFDM-V details




- 1 – Damper casing
- 2 – Shutting spring
- 3 – Locking planchet
- 4 – Damper blade
- 5 – Thermal fuse

2. Installation


2.1 Distances between the fire damper and the structure



2.2 Minimum duct dimensions from the structure




2.3 Mounting hole dimensions




*D – Duct

2.4 Wall structure (concrete and gypsum)




*A – Gypsum, mortar, mixture

2.5 Adding a coupling NIL




*B – Lubricant (Superglidex)


2.6 CFDM preparation



2.7 CFDM installation



2.8 Fixing the NIL





ETS NORD AS

Address: Peterburi tee 53
11415 Tallinn
Estonia

Phone: +372 680 7360
info@etsnord.ee
www.etsnord.ee

ETS NORD Finland

Address: Pakkasraitti 4
04360 Tuusula
Finland

Phone: +358 40 184 2842
info@etsnord.fi
www.etsnord.fi

ETS NORD Sweden

Address: Järsjögatan 7
692 35 Kumla
Sweden

Phone: +46 19 554 20 50

Address: Pinjegatan 5
213 63 Malmö
Sweden

Phone: +46 40 94 68 70


Address: Förrådsvägen 5
151 58 Södertälje
Sweden

Phone: +46 8 550 301 40

info@etsnord.se
www.etsnord.se

ETS NORD International

info@etsnord.com
www.etsnord.com



*Let's move the air **together!***