



NORDdiffuser
DEP Installation manual

Installation manual



Nominal size	Ød	A	H	ØD	h	l
100-300	100	300	47	130	45	40
125-350	125	350	47	170	50	40
160-350	160	350	47	210	55	40
200-450	200	450	47	250	55	40
200-600	200	595	47	250	55	40
250-450	250	450	47	300	55	40
250-600	250	595	47	300	55	40
315-600	315	595	47	365	55	40
400-600	400	595	47	450	90	75




DEP + SKDM



DEP + KRI





Supply

DEP + SKDM K-factor

Nominal size	Position							
	1	2	3	4	5	6	7	8
DEP 125-300 + SKDM 100/125	2,15	3,92	5,43	6,46				
DEP 160-300 + SKDM 125/160	2,38	4,18	5,86	7,26	8,43	9,22		
DEP 200-600 + SKDM 160/200	3,6	6,68	9,45	11,7	13,8	15,5		
DEP 250-600 + SKDM 200/250	4,85	9,51	14,4	19,3	23,8	27,6		
DEP 315-600 + SKDM 250/315	6,69	12,4	17,9	22,7	26,4	29		
DEP 400 + SKDM 315/400	6,98	14	20,6	26,9	31,9	36,5	40,1	43,2

Exhaust

DEP + SKDM K-factor

Nominal size	Position							
	1	2	3	4	5	6	7	8
DEP 125-300 + SKDM 100/125	2,12	4,07	6,08	8,16				
DEP 160-300 + SKDM 125/160	2,22	4,19	6,33	8,65	11,2	13,2		
DEP 200-600 + SKDM 160/200	3,37	6,73	10,4	14,1	17,9	21		
DEP 250-600 + SKDM 200/250	5,16	9,83	14,2	17,9	20,8	22,3		
DEP 315-600 + SKDM 250/315	6,73	12,3	18,5	24,4	30,3	32,4		
DEP 400-600 + SKDM 315/400	5,76	14,8	21,5	28,3	34,8	40,6	45,2	18,1



ETS NORD AS

Address: Peterburi tee 53
11415 Tallinn
Estonia

Phone: +372 680 7360
info@etsnord.ee
www.etsnord.ee

ETS NORD Finland

Address: Pakkasraitti 4
04360 Tuusula
Finland

Phone: +358 401 842 842
info@etsnord.fi
www.etsnord.fi

ETS NORD Sweden

Address: Järsjögatan 7
69235 Kumla
Sweden

Phone: +46 19 554 20 50

Address: Pinjegatan 5
21363 Malmö
Sweden

Phone: +46 40 94 68 70
info@etsnord.se
www.etsnord.se

Let's move the air together!