



NORDfire

FDMB Fire Damper

Square dampers from 160×160 mm to 0,5 m² (max. dimensions 1000×500 mm)

CE certified acc. to EN 15650

Fire resistance up to EIS 120

External Casig leakage class C, Internal leakage class 2 acc. to EN 1751

Damper actuating mechanical, or electrical

Contents

1. Description	3
2. Design	4
3. Dimensions, weighs and effective area	8
4. Placement and Assembly	16
5. Statement of installations	18
6. Installation frames	43
7. Suspension systems	44
8. Pressure loss	48
9. Noise data	49
10. Material, finishing	51
11. Inspection, testing	51
12. Transportation and storage	52
13. Assembly	52
14. Entry into service and revisions	52
15. Spare parts	54
16. Restore function of actuating mechanism after fuses initiation	54
17. Ordering key	54

General information

1. Description

Fire dampers are shutters in ducts of air-conditioning devices that prevent spreading the fire and combustion products from one fire segment to the other one by means of closing the duct in the points of fire separating constructions.

Dampers blade automatically closes air duct using a shutting spring or an actuating mechanism back spring. The shutting spring is started by releasing an initiation lever. The impulse for releasing the lever can be either a manual one, a thermal one. The back spring of the actuating mechanism is started when the thermoelectrical starting mechanism BAT is activated, when a reset button on BAT is pushed or when a power supply of the actuating mechanism is stopped. The damper is sealed with a silicon packing against smoke penetration after closing the blade. At the same time, the damper blade is bedded in a material which enlarges its capacity and air proofs the air duct.

Dampers have two inspection holes.

Fig. 1 FDMB with actuating mechanism



Fig. 2 FDMB with mechanical control



1.1 Damper characteristics

- CE certified acc. to EN 15650
- Tested in accordance with EN 1366-2
- Classified acc. to EN 13501-3+A1
- Fire resistance EIS 120, EIS 90
- External Casing leakage class C, Internal leakage class 2 acc. to EN 1751
- Cycling test in class C 10000 acc. to EN 15650
- Corrosion resistant acc. to EN 15650
- Certificate of constancy of performance No. 1391-CPR-2023/0166
- Declaration of Performance No. PM/FDMQ/01/23/3
- Hygienic assessment of fire dampers - Report No. 1.6/pos/19/19b

1.2 Working conditions

Right damper function is secured under the following conditions:

- a) Maximum air circulation speed: 12 m/s; maximum pressure difference: 1200 Pa
- b) The air circulation in the whole damper section must be secured as steady on whole surface

Operation of the dampers does not depend on the direction of air circulation. The dampers can be located in an arbitrary position.

Dampers are designed for macroclimatic areas with mild climate according to EN 60 721-3-3.

Dampers are suitable for systems without abrasive, chemical and adhesive particles.

Temperature in the place of installation is permitted to range from -30 °C to +50 °C.

If electric elements are installed on the damper, the temperature range is narrowed according to the temperature range of the electric elements used (see chapter 2 "Design").


2. Design

2.1 Design with mechanical control

Design .01

Design with mechanical control with a thermal protective fuse which actuates the shutting device, after the nominal start temperature 72°C has been reached. Automatic initiation of the shutting device is not activated if the temperature does not exceed 70°C. In case that other start temperatures are required, thermal fuses with nominal start temperature +104°C or +147°C can be supplied (this requirement must be specified in the order).

Fig. 3 Design.01



ATTENTION!

Mechanisms are produced in four designs M1 to M4, difference is only in size of inner spring, which closes the fire damper. For the size of fire dampers is always assigned the size of mechanism - Tab. 3. It is not recommended to use different size of mechanism, than given by the manufacturer, otherwise, there is a risk of fire damper destruction

Design .80

Design .01 with mechanical control can be complemented with a terminal switches signaling of the damper blade position "CLOSED" and "OPEN". Limit switches are connected via damper casing, cables are connected directly to limit switches.

Fig. 4 Design .80





Fig. 5 Limit switch G905-300E03W1




Nominal voltage and maximal current	AC 230 V / 5A
Class of protection	IP 67
Working temperature	-25 °C...+120 °C

This limit switch is possible to connect in following two versions:

- a) CUT-OFF if the arm is moving ... connect wire 1+2
- b) SWITCH-ON if the arm is moving ... connect wire 1+4

Fig. 6 Change of mechanical design for the motorised one or vice versa



Position:

- 1 – Damper
- 2 – Mounting plate
- 3 – Sealing cover
- 4 – Seal plates
- 5 – Mounting plate cover
- 6 – Thermal fuse
- 7 – Mechanics
- 8 – Actuator
- 9 – Temperature sensor
- 10 – Sensor sticker

2.2 Design with actuating mechanism

Design .40, .50

The damper are equipped by Belimo actuators with spring return and thermoelectric activation device of BFL, BFN or BF depending on the damper size (further mentioned as „actuators“). After being connected to power supply AC/DC 24V or 230V, the actuating mechanism displaces the damper blade into operation position "OPEN" and at the same time it pre-stretches its back spring. When the actuating mechanism is under voltage, the damper blade is in the position "OPEN" and the back spring is pre-stretched. Time needed for full opening of the flap blade from the position "CLOSED" to the position "OPEN" is maximum 120 sec. If the actuating power supply is cut off (due to loss of supply voltage, or pushing the reset button on the thermoelectrical starting mechanism BAT), the back spring displaces the damper blade into the breakdown position "CLOSED". The time of displacing the blade from the position "OPEN" to the position "CLOSED" takes maximum 20 sec. In case that the power supply is restored again (the blade can be in any position), the actuating mechanism starts to re-displace the damper blade into the position "OPEN". A thermoelectrical starting mechanism BAT, which contains two thermal fuses Tf1 and Tf2, is a part of the actuating mechanism. These fuses are activated when temperature +72°C has been exceeded (the fuse Tf1 when the temperature around the damper and the fuses Tf2 when the temperature inside the air-conditioning piping has been exceeded). After the thermal fuse Tf1 or Tf2 has been activated, the power supply is permanently and irreversibly cut off and the actuating mechanism, by means of the pre-stretched spring, displaces the damper blade into the breakdown position "CLOSED". Signalisation of damper blade position "OPEN" a "CLOSE" is provided by two limit switches.

Fig. 8 Design .40, .50




Fig. 7 Actuating mechanism BELIMO BFL (BFN) 230-T

AC230 V





Fig. 9 Actuating mechanism BELIMO BFL (BFN) 24-T(-ST)

AC/DC 24




Tab. 1. Actuating mechanism BELIMO BFL 24-T(-ST), BFN 24-T(-ST), BFL 230-T a BFN 230-T

Actuating mechanism BELIMO	BFL, BFN 230-T	BFL, BFN 24-T(-ST)
Nominal voltage	AC 230 V 50/60 Hz	AC 24 V 50/60 Hz DC 24 V
Power consumption		
- motoring	3,5/5 W	2,5/4 W
- holding	1,1/2,1 W	0,8/1,4 W
Dimensioning	6,5/10 VA (Imax 4 A @ 5 ms)	4/6 VA (Imax 8,3 A @ 5 ms)
Protection class	II	III
Degree of protection	IP 54	
Running time		
- motor	<60 s	
- spring return	~ 20 s	
Ambient temperature		
- normal duty	-30°C ... +55°C	
- safety duty	The safe position will be attained up to max +75°C	
- non-operating temperature	-40°C ... +55°C	
Connecting	cable 1 m, 2 × 0,75 mm² (BFL/BFN 24-T-ST) with 3-pin plug-in connectors	
- motor	cable 1 m, 6 × 0,75 mm² (BFL/BFN 24-T-ST) with 6-pin plug-in connectors	
- auxiliary switch		
Thermal trips	duct outside temperature +72°C duct inside temperature +72°C	

Fig. 10 Actuating mechanism BELIMO BF 230-TN, BF 24-ST

± ~ AC 24 V
 - + DC 24 V
 N L1 AC230 V



Tab. 2. Actuating mechanism BELIMO BF 24-TN(-ST), BF 230-TN

Actuating mechanism BELIMO	BF 24-TN(-ST)	BF 230-TN
Nominal voltage	AC 24 V 50/60 Hz DC 24 V	AC 230 V 50/60 Hz
Power consumption		
- motoring	7 W	8 W
- holding	2 W	3 W
Dimensioning	10 VA (Imax 8,3 A @ 5 ms)	12,5 VA (Imax 500 mA @ 5 ms)
Protection class	III	II
Degree of protection	IP 54	
Running time		120 sec
- motor		~ 16 sec
- spring return		
Ambient temperature		-30°C ... +50°C
- normal duty		The safe position will be attained up to max. +75°C
- safety duty		-40°C ... +50°C
- non-operating temperature		
Connecting - motor	cable 1 m, 2 x 0,75 mm ²	
- auxiliary switch	cable 1 m, 6 x 0,75 mm ²	
(BF 24-TN-ST) with plug-in connectors		
Thermal trips	Tf1: duct outside temperature +72°C Tf2/Tf3: duct intside temperature +72°C	

3. Dimensions, weighs and effective area

3.1 Dimensions

Fig. 11 Design with mechanical control





Fig. 12 Design with actuating mechanism



* X=14 (A<160 or B<160)

* X=23 (Ax B < 500x400)

* X=36 (Ax B > 500x400)

Position:

- 1 – Damper casing
- 2 – Actuating mechanism
- 3 – Damper blade
- 4 – Inspection hole covering
- 5 – BAT thermoelectrical starting mechanism
- 6 – Hole for camera

Tab. 3. Dimensions, weights and effective area

A x B (mm)	a	c	Weight		effect. area Sef. (m ²)	Actu. mech.	Mech. contr.	A x B (mm)	a	c	Weight		effect. area Sef. (m ²)	Actu. mech.	Mech. contr.
			mech (kg)	servo (kg)							mech (kg)	servo (kg)			
100 x 100	-	-	4,5	5,7	0,0030	BFL	M1	x 160	-	20	5,7	6,9	0,0099	BFL	M1
x 110	-	-	4,6	5,8	0,0037	BFL	M1	x 180	-	30	6,0	7,2	0,0118	BFL	M1
x 125	-	-	4,8	6,0	0,0048	BFL	M1	x 200	-	40	6,2	7,4	0,0138	BFL	M1
x 140	-	5	5,0	6,2	0,0059	BFL	M1	x 225	-	52,5	6,4	7,6	0,0162	BFL	M1
x 150	-	15	5,2	6,4	0,0066	BFL	M1	x 250	-	65	6,7	7,9	0,0186	BFL	M1
x 160	-	20	5,5	6,7	0,0073	BFL	M1	x 280	-	80	7,2	8,4	0,0215	BFL	M1
x 180	-	30	5,7	6,9	0,0088	BFL	M1	140 x 100	-	-	4,9	6,1	0,0047	BFL	M1
x 200	-	40	5,9	7,1	0,0102	BFL	M1	x 110	-	-	5,0	6,2	0,0058	BFL	M1
x 225	-	52,5	6,1	7,3	0,0120	BFL	M1	x 125	-	-	5,2	6,4	0,0075	BFL	M1
x 250	-	65	6,4	7,6	0,0138	BFL	M1	x 140	-	5	5,5	6,7	0,0092	BFL	M1
x 280	-	80	6,9	8,1	0,0160	BFL	M1	x 150	-	15	5,6	6,8	0,0103	BFL	M1
110 x 100	-	-	4,6	5,8	0,0034	BFL	M1	x 160	-	20	5,9	7,1	0,0114	BFL	M1
x 110	-	-	4,7	5,9	0,0043	BFL	M1	x 180	-	30	6,1	7,3	0,0137	BFL	M1
x 125	-	-	4,9	6,1	0,0055	BFL	M1	x 200	-	40	6,3	7,5	0,0159	BFL	M1
x 140	-	5	5,2	6,4	0,0067	BFL	M1	x 225	-	52,5	6,5	7,7	0,0187	BFL	M1
x 150	-	15	5,3	6,5	0,0075	BFL	M1	x 250	-	65	6,9	8,1	0,0215	BFL	M1
x 160	-	20	5,6	6,8	0,0084	BFL	M1	x 280	-	80	7,4	8,6	0,0249	BFL	M1
x 180	-	30	5,8	7,0	0,0100	BFL	M1	150 x 100	-	-	5,0	6,2	0,0051	BFL	M1
x 200	-	40	6,0	7,2	0,0116	BFL	M1	x 110	-	-	5,1	6,3	0,0063	BFL	M1
x 225	-	52,5	6,2	7,4	0,0137	BFL	M1	x 125	-	-	5,3	6,5	0,0082	BFL	M1
x 250	-	65	6,5	7,7	0,0157	BFL	M1	x 140	-	5	5,6	6,8	0,0100	BFL	M1
x 280	-	80	7,0	8,2	0,0182	BFL	M1	x 150	-	15	5,7	6,9	0,0112	BFL	M1
125 x 100	-	-	4,7	5,9	0,0041	BFL	M1	x 160	-	20	6,0	7,2	0,0124	BFL	M1
x 110	-	-	4,9	6,1	0,0050	BFL	M1	x 180	-	30	6,2	7,4	0,0149	BFL	M1
x 125	-	-	5,1	6,3	0,0065	BFL	M1	x 200	-	40	6,5	7,7	0,0173	BFL	M1
x 140	-	5	5,3	6,5	0,0080	BFL	M1	x 225	-	52,5	6,7	7,9	0,0204	BFL	M1
x 150	-	15	5,4	6,6	0,0089	BFL	M1	x 250	-	65	7,0	8,2	0,0234	BFL	M1

A x B (mm)	a	c	Weight		effect. area Sef. (m ²)	Actu. mech.	Mech. contr.
			mech (kg)	servo (kg)			
1000x280	-	80	18,8	20,0	0,1830	BFL	M2
x 300	-	90	19,7	21,2	0,2019	BFN	M2
x 315	-	97,5	20,1	21,6	0,2161	BFN	M2
x 355	-	117,5	21,7	23,2	0,2541	BFN	M2


A x B (mm)	a	c	Weight		effect. area Sef. (m ²)	Actu. mech.	Mech. contr.
			mech (kg)	servo (kg)			
1000x400	-	140	23,2	24,7	0,2967	BFN	M2
x 450	-	165	24,7	26,2	0,3441	BFN	M2
x 500	-	190	26,1	28,9	0,3915	BF	M2

3.2 Blades overlaps

Blades overlaps			Dimensions		Overlaps	
Blades overlaps		Fig. 13	Act. mechanism side		"a"	Table 3
			Side without act. mechanism		"c"	Table 3

These values have to be respected when projecting related air-conditioning.


Fig. 13 Blades overlaps




Dampers can be supplied on the customer's demands in all subdimension of the above mentioned range.

Fig. 14 Flanges of dampers

Operator side



Installation side



4. Placement and Assembly

Fire dampers are suitable for installation in arbitrary position in vertical and horizontal passages of fire separating constructions. Damper assembly procedures must be done so as all load transfer from the fire separating constructions to the damper body is absolutely excluded. Back-to-back air-conditioning piping must be hung or supported so as all load transfer from the back-to-back piping to the damper is absolutely excluded. Installation gap must be filled by approved material perfectly in all the installation space volume (installation gap).

To provide needed access space to the control device, all other objects must be situated at least 350 mm from the control parts of the damper. Inspection hole must be accessible.

Damper blade has to be inside of construction (labelled with BUILD IN EDGE on the damper body) after installation. The fire damper can also be installed outside the wall construction. Duct and the damper part between the wall construction and the damper blade (labelled with BUILD IN EDGE on the protective covering) must be protected with firefighting insulation.

The distance between the fire damper and the construction (wall, ceiling) must be minimum 75 mm. In case that two or more dampers are supposed to be installed in one fire separating construction, the distance between the adjacent dampers must be at least 200 mm according to EN 1366-2 paragraph 13.5.

Exceptions are given in chapter 5.

Fig. 16 The distance between the fire damper and the construction






Fig. 15 Built in edge

The damper must be installed so that the entire damper blade - in the closed position - is located inside the fire separating structure (wall) and at the same time the control mechanism and inspection openings are freely accessible. „Built-in edge label” indicates the maximum edge of installation of fire damper into the fire partition structure.



The control mechanism has to be protected (covered) against damage and pollution during installation process. All fire dampers has to be closed during installation process. The damper body should not be deformed in the course of bricking in. Once the damper is built in, its blade should not grind on the damper body during opening or closing.

Fig. 17 Installation opening



4.1 Examples of fire damper installing

The fire damper can be integrated into a solid wall construction made e.g. of normal concrete/ masonry, porous concrete with minimum thickness 100 mm or into solid ceiling construction made e.g. of normal concrete with minimum thickness 110 mm or porous concrete with minimum thickness 125 mm. The fire damper can be integrated into a gypsum wall construction with fire classification EI 120 or EI 90. The fire damper can also be integrated outside the wall construction. Duct and the damper part between the wall construction and the damper blade (labelled with BUILD IN EDGE on the protective covering) must be protected with fire-fighting insulation. If is damper installed outside a construction it is necessary to use reinforcement VRM for dampers with dimension $A \geq 800$ mm.

Important! For lower fire resistance than EI 90 the reinforcement VRM-B is not necessary!

5. Statement of installations

Tab. 4. Installation method list

Fire separating constru.	Wall/Ceiling	Installation	Fire resist.	Page
	Min. thickness [mm]			
Solid wall construction	100	Mortar or gypsum	EIS 120 EIS 90	19
	100	Stuffing box with fire protection mastic	EIS 60	19
	100	Fire protection foam with stucco plaster	EIS 60 EIS 45 EIS 30	20
	100	Battery - mortar or gypsum	EIS 90	21
	100	Installation next to wall - mortar or gypsum and mineral wool	EIS 90	22
	100	Stuffing box with fire protection mastic and cement lime plate	EIS 90	23
	100	Weichschott	EIS 90	24
Outside solid wall construction	100	Mineral wool - mortar or gypsum	EIS 60	25
	100	Mineral wool - stuffing box and fire protection mastic	EIS 60	26
	100	Mineral wool, stuffing box, fire protection mastic and cement lime plate	EIS 90 EIS 120	27
Gypsum wall construction	100	Mortar or gypsum	EIS 120 EIS 90	28
	100	Stuffing box with fire protection mastic	EIS 60	28
	100	Fire protection foam with stucco plaster	EIS 60 EIS 45 EIS 30	29
	100	Battery - mortar or gypsum	EIS 90	30
	100	Installation next to wall - mortar or gypsum and mineral wool	EIS 90	19
	100	Stuffing box with fire protection mastic and cement lime plate	EIS 90	32
	100	Weichschott	EIS 90	33
Outside gypsum wall construction	100	Mineral wool - mortar or gypsum	EIS 60	34
	100	Mineral wool - stuffing box and fire protection mastic	EIS 60	35
	100	Mineral wool, stuffing box, fire protection mastic and cement lime plate	EIS 90 EIS 120	36
Solid ceiling construction	110 - Concrete 125 - Aerated concrete	Mortar or gypsum	EIS 120 EIS 90	37
		Stuffing box with fire protection mastic	EIS 60	37
		Battery - mortar or gypsum	EIS 90	38
		Stuffing box with fire protection mastic and cement lime plate	EIS 90	39
		Weichschott	EIS 90	40
Outside solid ceiling construction	110 - Concrete 125 - Aerated concrete	Mineral wool - mortar or gypsum	EIS 90 EIS 120	41
		Concrete	EIS 90	42

5.1 Installation in solid wall construction

Fig. 18 Solid wall construction - mortar or gypsum

** the requirement to EIS 120 must be specified in the order alone. Without specifications is supplied the standard flap EIS 90





Fig. 19 Solid wall construction - stuffing box and fire protection mastic




Used materials - example:*

- 3 Promapyr, Rockwool Steprock HD, Hilti CFS-CT B 1S 140/50
- 4 Promastop - P, K, Hilti CFS-CT

Fig. 20 Solid wall construction - fire protection foam with stucco plaster

Maximal damper dimensions 400x400 mm

EIS 60
EIS 45
EIS 30



Position:



- 1 – Fire damper
- 2 – Solid wall construction
- 3 – Fire protection foam
- 4 – Stucco plaster
- 5 – Duct

Used materials - example:


- 3 HILTI CFS-F FX - EIS 60
- PROMAFOAM-C - EIS 45
- SOUDAL, Soudafoma FR-B1 - EIS 30
- DenBraven, Fire protection foam - EIS 30

Fig. 21 Solid wall construction - battery - mortar or gypsum

EIS 90


Position:


- 1 – Fire damper
- 2 – Solid wall construction
- 3 – Mortar or gypsum


Notice:

- Installation opening for each damper has minimal dimensions $a \times b = (A+100) \times (2xB +100)$ mm or $(2xA+100) \times (B +100)$ mm
- Gap between damper and construction is filled by mortar or gypsum
- Distance between dampers 60 mm
- Flange to flange connection - Up to 4 dampers can be installed

Fig. 22 Solid wall construction - installation next to wall, ceiling - mortar or gypsum and mineral wool.

EIS 90



Position:

- 1 – Fire damper
- 2 – Mortar or gypsum
- 3 – Mineral stone wool min. density 140 kg/m³


Notice:

- Gap between damper and construction is filled by mortar or gypsum and mineral wool
- Wool is fixed to damper body and construction by fire protection mastic
- Mineral wool thickness = construction thickness + 20 mm or 50 mm
- Installation is valid for ceiling construction

Fig. 23 Solid wall construction - stuffing box, fire protection mastic and cement lime plate



Ensure symmetry with rod location



Screws has to be fixed in wall/ ceiling construction
(If it is needed use steel bracket).


Position:

- 1 – Fire damper
- 2 – Solid wall construction
- 3 – Stuffing box (mineral stone wool min. density 140 kg/m³)
- 4 – Fire protection mastic min. thickness 1 mm
- 5 – Cement lime plate min. thickness 15 mm min. density 870 kg/m³
- 6 – Duct

Used materials - example:

- 3 Promapyr, Rockwool Steprock HD, Hilti CFS-CT B 1S 140/50
- 4 Promastop - P, K, Hilti CFS-CT
- 5 Promatect - H

Fig. 24 Solid wall construction - Weichschott

**Position:**


- 1 – Fire damper
- 2 – Solid wall construction
- 3 – Fire resistant board
- 4 – Fire stop coating thickness 1 mm
- 5 – Duct
- 6 – Protective cladding boards - (not part of the damper) but must be used as part of the penetration filling. It can be ordered from MANDÍK as an accessory.
- 7 – Fire resistant mastic - fill the gap on both sides of the fire separation construction and around the perimeter of penetration and damper body.

Used materials - example:

- 3 Hilti CFS-CT B 1S 140/50
- 4 Hilti CFS-CT
- 6 PROMATECT-H
 - for AxB ≤ 500x400, th. 10 mm
 - for AxB > 500x400, th. 15 mm
- 7 Hilti CFS-S ACR

5.2 Installation outside solid wall construction

Fig. 25 Outside solid wall construction - mineral wool - mortar or gypsum



Position:

- 1 – Fire damper
- 2 – Solid wall construction
- 3 – Mortar or gypsum
- 4 – Insulation board made of stone wool, with a surface treatment of aluminum foil, density 66 kg/m³
- 5 – Duct
- 6 – Apply ISOVER Protect BSK glue on the insulation and stick it to the fire separation construction ***

*** When installing the insulation, follow the ISOVER manufacturer's instructions.

The maximum distance of the fire damper from the structure is not limited and according to EN 15882-2, the required number of suspensions acc. to EN 1366-1:2014 must be used.


Used materials - example:**

- 4 - Isover Ultimate Protect SLAB 4.0, th. 80 mm ALU1

** Fire resistant insulation and fire resistant board can be replaced by another approved fire sealing system for damper installation with equivalent material properties.

The duct at the point of penetration does not have to be anchored to the fire wall construction.

Fig. 26 Outside solid wall construction - mineral wool - stuffing box and protection mastic



Position:

- 1 – Fire damper
- 2 – Solid wall construction
- 3 – Stuffing box (mineral stone wool min. density 140 kg/m³)
- 4 – Fire protection mastic min. thickness 1 mm
- 5 – Insulation board made of stone wool, with a surface treatment of aluminum foil, density 66 kg/m³
- 6 – Duct
- 7 – Apply ISOVER Protect BSK glue on the insulation and stick it to the fire separation construction ***

*** When installing the insulation, follow the ISOVER manufacturer's instructions.

The maximum distance of the fire damper from the structure is not limited and according to EN 15882-2, the required number of suspensions acc. to EN 1366-1:2014 must be used.

Used materials - example:**

- 3 Promapyr, Rockwool Steprock HD, Hilti CFS-CT B 1S 140/50
- 4 Promastop - P, K, Hilti CFS-CT
- 5 Isover Ultimate Protect SLAB 4.0, th. 80 mm ALU1



** Fire resistant insulation and fire resistant board can be replaced by another approved fire sealing system for damper installation with equivalent material properties.

The duct at the point of penetration must be anchored to the fire wall construction.

Fig. 27 Outside solid wall construction - mineral wool, stuffing box, fire protection mastic and cement lime plate

EIS 90

EIS 120 ****



Position:

Screws has to be fixed in wall/ ceiling construction
(If it is needed use steel bracket).

- 1 – Fire damper
- 2 – Solid wall construction
- 3 – Mineral stone wool min. density 140 kg/m³
- 4 – Fire protection mastic min. thickness 1 mm
- 5 – Cement lime plate min. thickness 15 mm (min. density 870 kg/m³)
- 6 – Stone wool bound with use of an organic resin with crushed stone as a refrigerant, min. density 300 kg/m³ and min. thickness 60 mm
- 7 – Steel sheet reinforcement U25x40x25 placed between layers of stone wool
- 8 – VRM***
- 9 – Duct
- 10 – Apply Rockwool Firepro glue on the insulation and stick it to the fire separation construction ****

Used materials - example:**

- 3 Promapyr, Rockwool Steprock HD, Hilti CFS-CT B 1S 140/50
- 4 Promastop - P, K, Hilti CFS-CT
- 5 Promatect - H
- 6 Rockwool Conlit Ductrock EIS 90, th. 60 mm

** Stuffing box, fire protection mastic, cement lime plate and insulation materials can be replaced by another approved fire sealing system for damper installation with equivalent material properties.

*** Depends on the distance of the flap from the construction, when the maximum distance from the construct is not limited and according to EN 15882-2 must use the required number of hinges according to EN 1366-1:2014.

**** Reinforcement fixing VRM see Fig. 81 Installation of profile U25x40x25 see Fig. 82

***** When using Rockwool Conlit Ductrock EIS 120, th. 60 mm, the overall fire resistance of the EIS 120 can be achieved.
T - thickness of the insulation (mm)

***** When installing the insulation, follow the Rockwool manufacturer's instructions.

The duct at the point of penetration must be anchored to the fire wall construction.

5.3 Installation in gypsum wall construction i

Fig. 28 Gypsum wall construction - mortar or gypsum





Fig. 29 Gypsum wall construction - stuffing box and fire protection mastic




Used materials - example:

- 4 Promapyr, Rockwool Steprock HD, Hilti CFS-CT B 1S 140/50
- 5 Promastop - P, K, Hilti CFS-CT

Fig. 30 Gypsum wall construction - fire protection foam with stucco plaster

Maximum damper dimensions 400 x 400 mm




Position:

- 1 – Fire damper
- 2 – Gypsum plate
- 3 – Mineral wool (type depending on the type of construction)
- 4 – Fire protection foam
- 5 – Stucco plaster
- 6 – Duct

Used materials - example:

- 4 HILTI CFS-F FX - EIS 60
- PROMAFOAM-C - EIS 45
- SOUDAL, Soudafoma FR-B1 - EIS 30
- DenBraven, Fire protection foam - EIS 30

Fig. 31 Gypsum wall construction - battery - mortar or gypsum



Position:

- 1 – Fire damper
- 2 – Gypsum plate
- 3 – Mineral wool (type depending on the type of construction)
- 4 – Mortar or gypsum

Notice:

- Installation opening for each damper has minimal dimensions $a \times b = (A+100) \times (2xB + 100) \text{ mm}$ or $(2xA+100) \times (B + 100) \text{ mm}$
- Gap between damper and construction is filled by mortar or gypsum
- Distance between dampers 60 mm 4 Mortar or gypsum
- Flange to flange connection - Up to 4 dampers can be installed

Fig. 32 Gypsum wall construction - installation next to wall, ceiling - mortar or gypsum and mineral wool



Position:



- 1 – Fire damper
- 2 – Mortar or gypsum
- 3 – Mineral stone wool min. density 140 kg/m³

Notice:

- Gap between damper and construction is filled by mortar or gypsum and mineral wool
- Wool is fixed to damper body and construction by fire protection mastic
- Mineral wool thickness = construction thickness + 20 mm or 50 mm
- Installation is valid for ceiling construction

Fig. 33 Gypsum wall construction - stuffing box, fire protection mastic and cement lime plate

EIS 90



Screws has to be fixed in wall/ ceiling construction
(If it is needed use steel bracket).

Position:


- 1 – Fire damper
- 2 – Gypsum plate
- 3 – Mineral wool (type depending on the type of construction)
- 4 – Mineral stone wool min. density 140 kg/m³
- 5 – Fire protection mastic min. thickness 1 mm
- 6 – Cement lime plate min. thickness 15 mm (min. density 870 kg/m³)
- 7 – Duct

Used materials - example:

- 4 Promapyr, Rockwool Steprock HD, Hilti CFS-CT B 1S 140/50
- 5 Promastop - P, K, Hilti CFS-CT
- 6 Promatect - H

Fig. 34 Gypsum wall construction - Weichschott

EIS 90


Position:

- 1 – Fire damper
- 2 – Gypsum plate
- 3 – Mineral wool (type depending on the type of construction)
- 4 – Fire resistant board
- 5 – Fire stop coating thickness 1 mm
- 6 – Duct
- 7 – Protective cladding boards - (not part of the damper) but must be used as part of the penetration filling. It can be ordered from MANDIK as an accessory.
- 8 – Fire resistant mastic - fill the gap on both sides of the fire separation construction and around the perimeter of penetration and damper body.


Used materials - example:

- 4 Hilti CFS-CT B 1S 140/50
- 5 Hilti CFS-CT
- 7 PROMATECT-H
 - for $A \times B \leq 500 \times 400$, th. 10 mm
 - for $A \times B > 500 \times 400$, th. 15 mm
- 8 Hilti CFS-S ACR

5.4 Installation outside gypsum wall construction

Fig. 35 Outside gypsum wall construction - mineral wool - mortar or gypsum

EIS 60



Position:

- 1 – Fire damper
- 2 – Gypsum plate
- 3 – Mineral wool (type depending on the type of construction)
- 4 – Mortar or gypsum
- 5 – Insulation board made of stone wool, with a surface treatment of aluminum foil, density 66 kg/m³
- 6 – Duct
- 7 – Apply ISOVER Protect BSK glue on the insulation and stick it to the fire separation construction ***

Used materials - example:**

- 5 Isover Ultimate Protect SLAB 4.0, th. 80 mm ALU1

** Insulation materials can be replaced by another approved fire sealing system with equivalent properties.
The maximum distance of the fire damper from the structure is not limited


*** When installing the insulation, follow the ISOVER manufacturer's instructions.

** The materials for stuffing box, fire protection mastic, lining and insulation materials can be replaced by another approved fire sealing system with equivalent properties.
The maximum distance of the fire damper from the structure is not limited and according to EN 15882-2, the required number of suspensions acc. to EN 1366-1:2014 must be used.

The duct at the point of penetration does not have to be anchored to the fire wall construction.

Fig. 36 Outside solid wall construction - mineral wool - stuffing box and protection mastic

EIS 60

**Position:**

- 1 – Fire damper
- 2 – Gypsum plate
- 3 – Mineral wool (type depending on the type of construction)
- 4 – Stuffing box (mineral stone wool min. density 140 kg/m^3)
- 5 – Fire protection mastic min. thickness 1 mm
- 6 – Insulation board made of stone wool, with a surface treatment of aluminum foil, density 66 kg/m^3
- 7 – Duct
- 8 – Apply ISOVER Protect BSK glue on the insulation and stick it to the fire separation construction ***

*** When installing the insulation, follow the ISOVER manufacturer's instructions.

Used materials - example:**

- 4 Promapyr, Rockwool Steprock HD, Hilti CFS-CT B 1S 140/50
- 5 Promastop - P, K, Hilti CFS-CT
- 6 Isover Ultimate Protect SLAB 4.0, th. 80 mm ALU1


** Insulation materials can be replaced by another approved fire sealing system with equivalent properties.

The maximum distance of the fire damper from the structure is not limited

The duct at the point of penetration must be anchored to the fire wall construction.

Fig. 37 Outside solid wall construction - mineral wool, stuffing box, fire protection mastic and cement lime plate.

EIS 90
EIS 120 ****



Position:

1 – Fire damper
2 – Gypsum plate
3 – Mineral wool (type depending on the type of construction)
4 – Mineral stone wool min. density 140 kg/m³

5 – Fire protection mastic min. thickness 1 mm
6 – Cement lime plate min. thickness 15 mm (min. density 870 kg/m³)
7 – Stone wool bound with use of an organic resin with crushed stone as a refrigerant, min. density 300 kg/m³ and min. thickness 60 mm

8 – Steel sheet reinforcement U25x40x25 placed between layers of stone wool

9 – VRM****
10 – Duct

11 – Apply Rockwool Firepro glue on the insulation and stick it to the fire separation construction *****

Used materials - example:**

- 4 Promapyr, Rockwool Steprock HD, Hilti CFS-CT B 1S 140/50
- 5 Promastop - P, K, Hilti CFS-CT
- 6 Promatect - H
- 7 Rockwool Conlit Ductrock EIS 90, th. 60 mm

** Stuffing box, fire protection mastic, cement lime plate and insulation materials can be replaced by another approved fire sealing system for damper installation with equivalent material properties.

*** Depends on the distance of the flap from the construction, when the maximum distance from the construct is not limited and according to EN 15882-2 must use the required number of hinges according to EN 1366-1:2014.

**** For installation methods outside a construction, when the damper size is $A \geq 800$ mm, it is necessary to use the VRM reinforcing frame, see Fig.80. Assembly - reinforcing frame U25x40x25 see Fig.81.


***** When using Rockwool Conlit Ductrock EIS 120, th. 60 mm, the overall fire resistance of the EIS 120 can be achieved. T - thickness of the insulation (mm)

***** When installing the insulation, follow the Rockwool manufacturer's instructions.

The duct at the point of penetration must be anchored to the fire wall construction.

5.5 Installation in solid ceiling construction

Fig. 38 Solid ceiling construction - mortar or gypsum




Position:

- 1 – Fire damper
- 2 – Solid ceiling construction
- 3 – Mortar or gypsum
- 4 – Duct

* min 110 – Concrete/ min. 125 - Aerated concrete

** Around the perimeter

Fig. 39 Solid ceiling construction- stuffing box, fire protection mastic



Position:

- 1 – Fire damper
- 2 – Solid ceiling construction
- 3 – Stuffing box (mineral stone wool min. density 140 kg/m³)
- 4 – Fire protection mastic min. thickness 1 mm
- 5 – Duct

* min 110 – Concrete/ min. 125 - Aerated concrete


Used materials - example:

- 3 - Promapyr, Rockwool Steprock HD, Hilti CFS-CT B 1S 140/50
- 4 - Promastop - P, K, Hilti CFS-CT


Fig. 40 Solid ceiling construction - battery - mortar or gypsum

EIS 90

The gap 94 mm between dampers can be filled by mineral stone wool min. density 140 kg/m³. Wool is fixed to damper body by fire protection mastic.



The gap 94 mm between dampers can be filled by mineral stone wool min. density 140 kg/m³. Wool is fixed to damper body by fire protection mastic.


Position:

- 1 – Fire damper
- 2 – Solid wall construction
- 3 – Mortar or gypsum


Notice:

- Installation opening for each damper has minimal dimensions $a \times b = (A+100) \times (2xB +100)$ mm or $(2xA+100) \times (B +100)$ mm
- Gap between damper and construction is filled by mortar or gypsum
- Distance between dampers 60 mm
- Flange to flange connection - Up to 4 dampers can be installed

* min 110 – Concrete/ min. 125 - Aerated concrete

** Around the perimeter

Fig. 41 Solid ceiling construction - stuffing box, fire protection mastic and cement lime plate



* min 110 – Concrete/ min. 125 - Aerated concrete

** Around the perimeter

Position:


- 1 – Fire damper
- 2 – Solid ceiling construction
- 3 – Stuffing box (mineral stone wool min. density 140 kg/m³)
- 4 – Fire protection mastic min. thickness 1 mm
- 5 – Cement lime plate min. thickness 15 mm, min. density 870 kg/m³
- 6 – Duct

Used materials - example:

- 4 Promapyr, Rockwool Steprock HD, Hilti CFS-CT B 1S 140/50
- 5 Promastop - P, K, Hilti CFS-CT
- 6 Promatect - H

Fig. 42 Solid ceiling construction - Weichschott

EIS 90



Position:

- 1 – Fire damper
- 2 – Solid ceiling construction
- 3 – Fire resistant board
- 4 – Fire stop coating thickness 1 mm
- 5 – Duct
- 6 – Protective cladding boards - (not part of the damper)
but must be used as part of the penetration filling. It can
be ordered from MANDÍK as an accessory.
- 7 – Fire resistant mastic - fill the gap on both sides of the
fire separation construction and around the perimeter
of penetration and damper body.


* min 110 – Concrete/ min. 125 - Aerated concrete

Used materials - example:

- 3 Hilti CFS-CT B 1S 140/50
- 4 Hilti CFS-CT
- 6 PROMATECT-H
for AxB ≤ 500x400, th. 10 mm
for AxB > 500x400, th. 15 mm
- 7 Hilti CFS-S ACR

5.6 Installation outside solid ceiling construction

Fig. 43 Outside solid ceiling construction - mineral wool - mortar and gypsum



Position:

- 1 – Fire damper
- 2 – Solid ceiling construction
- 3 – Mortar or gypsum
- 4 – Stone wool bound with use of an organic resin with crushed stone as a refrigerant, min. density 300 kg/m³ and min. thickness 60 mm
- 5 – Steel sheet reinforcement U25x40x25 placed between layers of stone wool
- 6 – VRM****
- 7 – Duct
- 8 – Apply Rockwool Firepro glue on the insulation and stick it to the fire separation construction *****

* min 110 – Concrete/ min. 125 - Aerated concrete

** Around the perimeter

Used materials - example:

- 4 Rockwool Rockwool Conlit Ductrock EIS 90, th. 60 mm

*** Stuffing box, fire protection mastic, cement lime plate and insulation materials can be replaced by another approved fire sealing system for damper installation with equivalent material properties.

**** Depends on the distance of the flap from the construction, when the maximum distance from the construct is not limited and according to EN 15882-2 must use the required number of hinges according to EN 1366-1:2014.

***** For installation methods outside a construction, when the damper size is A ≥ 800 mm, it is necessary to use the VRM reinforcing frame, see Fig.80. Assembly - reinforcing frame U25x40x25 see Fig.81.


***** When using Rockwool Conlit Ductrock EIS 120, th. 60 mm, the overall fire resistance of the EIS 120 can be achieved. T - thickness of the insulation (mm)

***** When installing the insulation, follow the Rockwool manufacturer's instructions.

The duct at the point of penetration does not have to be anchored to the fire wall construction.

Fig. 44 Outside solid ceiling construction - Concrete


EIS 90



6. Installation frames

For dampers with $A \geq 800$ and damper placement outside wall construction is necessary to use reinforcement VRM


Fig. 45 Fixing of reinforcement to damper body VRM




Important: For lower resistance than EI90 the reinforcement VRM is not necessary!

Fig. 46 Installation procedure


1) Cut the groove for profil U25x40x25




2) Insert profile into groove



3) Fix profile




4) Fix second layer of insulation



Installation details see chapter 7 “Suspension systems”.

7. Suspension systems

Fig. 47 Mounting to the ceiling wall



Position:

- 1 – Threaded rod M8 – M20
- 2 – Nut
- 3 – Washer
- 4 – Coupling Nut
- 5 – Anchor
- 6 – Hinge plate - min. thickness 10 mm
- 7 – Concrete screw tested for fire resistance R30-R90, max. Tension up to 0.75 KN (length 35 mm)

Load capacities of threaded hanger rods
F [N] at the required resistance 90 minutes

Size	A_s (mm ²)	Weight G (kg)	
		for 1 piece	fot 1 pair
M8	36,6	22	44
M10	58	35	70
M12	84,3	52	104
M14	115	70	140
M16	157	96	192
M18	192	117	234
M20	245	150	300

7.1 Horizontal installation



Damper assembly procedures must be done so as all load transfer from the fire separating constructions to the damper body is absolutely excluded. Back-to-back air-conditioning piping must be hung or supported so as all load transfer from the back-to-back piping to the damper is absolutely excluded.

Threaded rods longer than 1,5 m require fire-resistant insulation.

Threaded rod fixing to the ceiling construction - see fig. 47

Fig. 48 Suspension - horizontal duct

EIS 90



Position:

- 1 – Fire damper
- 2 – Duct
- 3 – Mineral wool
- 4 – Threaded rod
- 5 – Mounting rail
- 6 – Nut
- 7 – U - Washer
- 8 – Washer

Used materials - example:
HILTI, SIKLA, MÜPRO etc.

7.2 Vertical installation

The damper must not be suspended or anchored. The duct must be anchored after national rules, like in fig. 85 - as an example. It can be suspended by using threaded rods and a mounting profiles. Load the suspension system depend on weight of the fire damper.


Damper can be suspended from the ceiling construction or supported above the ceiling construction.

Damper assembly procedures must be done so as all load transfer from the fire separating constructions to the damper body is absolutely excluded. Back-to-back air-conditioning piping must be hung or supported so as all load transfer from the back-to-back piping to the damper is absolutely excluded.

Threaded rods longer than 1,5 m require fire-resistant insulation.

Threaded rod fixing to the ceiling construction - see fig. 47.

Fig. 49 Suspension - vertical duct



7.3 Rectangular fire damper suspension on the wall - horizontal installation

Fire dampers installed remote from the wall must be suspended.

The duct must be suspended on both sides of damper after national rules.

Duct between fire damper and fire separating construction must be suspended by using threaded rods and mounting profiles, or another anchoring system according national standards. Load the suspension system depend on weight of the fire damper and duct system.

Max. length between two suspension systems is 1500 mm.

Damper assembly procedures must be done so as all load transfer from the fire separating constructions to the damper body is absolutely excluded. Back-to-back air-conditioning piping must be hung or supported so as all load transfer from the back-to-back piping to the damper is absolutely excluded.

Threaded rods longer than 1,5 m require fire-resistant insulation.


If the threaded rod is located inside the duct insulation, distance between threaded rod and duct is max 30 mm. If the threaded rod is located outside the duct isolation, distance between threaded rod and isolation is max. 40 mm. Thickness of the insulation under mounting profile must be min. 30 mm.

Threaded rod fixing to the ceiling construction - see fig. 47

The insulation boards are fastened to the duct.

For more information see documentation of insulation manufacturer


Fig. 50 Suspension on the wall - horizontal installation



Insulation layers on the duct

Position:

- 1 – Fire damper
- 2 – Duct
- 3 – Soft padding (stone wool + fire board)
- 4 – Threaded rod
- 5 – Mounting rail
- 6 – Nut
- 7 – Washer
- 8 – Weld pin
- 9 – Insulation*



* Fixing the insulation to duct acc. to fire insulation supplier's instructions.

Technical data

8. Pressure loss

8.1 Pressure loss calculation


$$\Delta p = \xi * \rho * (v^2 / 2)$$

Δp - pressure loss (Pa)

ξ - coefficient of local pressure loss for the nominal damper section (see Tab. 5)

ρ - air density (kg/m^3)

w - air flow speed in nominal damper section (m/s)



Determination of pressure loss by using diagram $\rho=1,2 \text{ kg/m}^3$

8.2 Coefficient of local pressure loss ξ (-)

Tab. 5.

A	B													
	100	110	125	140	150	160	180	200	225	250	280	300	315	355
100	19,025	15,910	11,370	7,983	6,374	5,264	2,959	2,962	2,162	1,548	1,399	-	-	-
110	15,690	12,678	9,499	6,910	5,576	4,528	2,743	2,649	1,978	1,459	1,299	-	-	-
125	11,247	9,984	7,440	5,444	4,529	3,773	2,461	2,208	1,744	1,327	1,163	-	-	-
140	8,673	7,669	5,933	4,489	3,755	3,195	2,204	1,893	1,552	1,217	1,044	-	-	-
150	7,408	6,620	5,144	4,007	3,388	2,899	2,091	1,728	1,443	1,160	0,985	-	-	-
160	6,659	5,813	4,748	3,683	3,129	4,771	3,458	2,717	2,285	1,813	1,538	1,407	1,327	1,165
180	4,528	4,270	3,630	3,000	2,644	4,102	3,251	2,351	2,016	1,676	1,342	1,221	1,136	0,986
200	4,490	4,170	3,466	2,807	2,446	3,701	2,951	2,105	1,867	1,554	1,302	1,113	1,052	0,933
225	4,220	3,969	3,379	2,767	2,431	3,654	2,873	2,056	1,726	1,475	1,226	1,067	1,029	0,917
250	4,120	3,904	3,306	2,744	2,405	3,588	2,793	2,005	1,675	1,386	1,155	1,033	0,987	0,893
280	3,520	3,404	3,005	2,551	2,266	3,411	2,692	1,975	1,599	1,341	1,123	0,986	0,916	0,822
300	3,307	3,225	2,876	2,457	2,189	3,288	2,599	1,903	1,536	1,315	1,101	0,974	0,911	0,787
315	3,219	3,139	2,760	2,338	2,072	3,102	2,454	1,833	1,489	1,289	0,988	0,933	0,833	0,721
355	2,914	2,842	2,550	2,195	1,963	2,955	2,302	1,796	1,412	1,199	0,956	0,902	0,799	0,678
400	3,291	3,125	2,665	2,196	1,926	2,833	2,159	1,703	1,356	1,126	0,931	0,825	0,711	0,635
450	-	-	2,690	2,176	1,884	2,732	2,055	1,623	1,302	1,103	0,852	0,777	0,677	0,599
500	-	-	2,590	2,110	1,836	2,670	1,988	1,587	1,251	1,025	0,796	0,725	0,618	0,529
550	-	-	1,976	1,885	1,731	4,219	2,941	2,237	1,687	1,402	1,156	1,039	0,968	0,827
560	-	-	1,978	1,884	1,727	4,194	2,922	2,222	1,623	1,392	1,147	1,031	0,910	0,820
600	-	-	-	1,841	1,696	4,104	2,857	2,170	1,573	1,357	1,117	1,004	0,935	0,797
630	-	-	-	1,828	1,682	4,046	2,814	2,137	1,553	1,334	1,098	0,986	0,918	0,782
650	-	-	-	1,814	1,670	4,010	2,788	2,116	1,526	1,320	1,086	0,975	0,908	0,773
700	-	-	-	-	1,664	3,975	2,759	2,098	1,515	1,297	1,071	0,965	0,892	0,761
710	-	-	-	-	1,645	3,918	2,720	2,062	1,496	1,284	1,055	0,947	0,881	0,749
750	-	-	-	-	1,630	3,865	2,682	2,032	1,475	1,264	1,037	0,931	0,866	0,736
800	-	-	-	-	1,612	3,808	2,640	1,999	1,445	1,241	1,018	0,913	0,849	0,721
900	-	-	-	-	-	3,715	2,572	1,946	1,414	1,205	0,988	0,885	0,822	0,697
1000	-	-	-	-	-	3,643	2,519	1,904	1,395	1,177	0,964	0,863	0,801	0,679

A	B													
	400	450	500	550	560	600	630	650	700	710	750	800	900	1000
100	—	—	—	—	—	—	—	—	—	—	—	—	—	—
110	—	—	—	—	—	—	—	—	—	—	—	—	—	—
125	—	—	—	—	—	—	—	—	—	—	—	—	—	—
140	—	—	—	—	—	—	—	—	—	—	—	—	—	—
150	—	—	—	—	—	—	—	—	—	—	—	—	—	—
160	1,040	2,025	1,874	1,761	1,741	1,672	1,627	1,601	1,598	1,532	1,493	1,452	1,386	1,336
180	0,922	1,676	1,548	1,451	1,434	1,375	1,337	1,315	1,289	1,256	1,224	1,180	1,133	1,090
200	0,801	1,445	1,332	1,246	1,232	1,179	1,146	1,126	1,106	1,074	1,046	1,015	0,965	0,928
225	0,781	1,239	1,172	1,075	1,035	0,998	0,965	0,938	0,926	0,905	0,873	0,856	0,822	0,803
250	0,736	1,113	1,021	0,952	0,940	0,898	0,871	0,855	0,831	0,813	0,790	0,765	0,725	0,695
280	0,713	0,996	0,912	0,849	0,880	0,800	0,775	0,760	0,742	0,722	0,701	0,678	0,641	0,613
300	0,692	0,937	0,857	0,797	0,786	0,750	0,726	0,712	0,689	0,675	0,655	0,633	0,599	0,572
315	0,634	0,900	0,822	0,764	0,754	0,718	0,695	0,681	0,662	0,646	0,626	0,605	0,572	0,546
355	0,588	0,821	0,749	0,694	0,685	0,651	0,630	0,617	0,603	0,584	0,566	0,546	0,514	0,490
400	0,527	0,757	0,689	0,637	0,628	0,597	0,577	0,565	0,543	0,534	0,516	0,498	0,468	0,445
450	0,507	0,705	0,640	0,591	0,583	0,553	0,534	0,522	0,503	0,493	0,476	0,458	0,430	0,408
500	0,460	0,666	0,603	0,556	0,548	0,520	0,501	0,490	0,482	0,462	0,446	0,429	0,401	0,380
550	0,719	0,635	0,575	0,529	0,521	0,494	0,476	0,465	0,441	0,437	0,422	0,405	0,379	—
560	0,713	0,630	0,570	0,524	0,517	0,489	0,471	0,461	0,448	0,433	0,418	0,401	—	—
600	0,692	0,611	0,552	0,507	0,500	0,473	0,455	0,445	0,426	0,418	0,403	0,387	—	—
630	0,678	0,598	0,540	0,496	0,489	0,462	0,445	0,435	0,418	0,408	0,393	—	—	—
650	0,670	0,590	0,533	0,490	0,482	0,456	0,439	0,428	0,414	0,402	0,387	—	—	—
700	0,656	0,581	0,527	0,483	0,476	0,444	0,431	0,421	0,409	0,398	—	—	—	—
710	0,648	0,571	0,515	0,472	0,465	0,439	0,422	0,412	0,399	—	—	—	—	—
750	0,636	0,560	0,504	0,462	0,455	0,429	0,413	0,403	—	—	—	—	—	—
800	0,623	0,547	0,493	0,451	0,444	0,419	—	—	—	—	—	—	—	—
900	0,602	0,528	0,474	0,434	—	—	—	—	—	—	—	—	—	—
1000	0,585	0,512	0,460	—	—	—	—	—	—	—	—	—	—	—

9. Noise data

9.1 Level of acoustic output corrected with filter A

$$L_{WA} = L_{W1} + 10 \log(S) + K_A$$

- L_{WA}** [dB(A)] level of acoustic output corrected with filter A
L_{W1} [dB] level of acoustic output L_{W1} related to the 1 m² section (see Tab. 6)
S [m²] duct cross section
K_A [dB] correction to the weight filter A (see Tab. 7)

9.2 Level of acoustic output in octave ranges

$$L_{Woct} = L_{W1} + 10 \log(S) + L_{rel}$$

- L_{Woct}** [dB] spectrum of acoustic output in octave range
L_{W1} [dB] level of acoustic output L_{W1} related to the 1 m² section (see Tab. 6)
S [m²] duct cross section
L_{rel} [dB] relative level expressing the shape of the spectrum (see Tab. 8)

9.3 Table of acoustics values

Tab. 6. Level of acoustic output LW1 [dB] related to the 1 m² section

v (m/s)	$\xi (-)$														
	0,2	0,3	0,4	0,5	0,6	0,7	0,8	0,9	1,0	1,5	2,0	2,5	3,0	4,0	5,0
2	15,5	18,7	20,9	22,6	24	25,2	26,3	27,2	28	31,2	33,4	35,1	36,5	38,8	40,5
3	26,1	29,2	31,5	33,2	34,6	35,8	36,9	37,8	38,6	41,7	44	45,7	47,1	49,4	51,1
4	33,6	36,7	39	40,7	42,1	43,3	44,3	45,3	46,1	49,2	51,5	53,2	54,6	56,9	58,6
5	39,4	42,5	44,8	46,5	47,9	49,1	50,2	51,1	51,9	55	57,3	59	60,4	62,7	64,4
6	44,1	47,3	49,5	51,3	52,7	53,9	54,9	55,8	56,6	59,8	62	63,8	65,2	67,4	69,2
7	48,2	51,3	53,5	55,3	56,7	57,9	58,9	59,8	60,7	63,8	66,1	67,8	69,2	71,4	73,2
8	51,6	54,8	57	58,8	60,2	61,4	62,4	63,3	64,1	67,3	69,5	71,3	72,7	74,9	76,7
9	54,7	57,9	60,1	61,8	63,2	64,4	65,5	66,4	67,2	70,4	72,6	74,3	75,7	78	79,7
10	57,4	60,6	62,8	64,6	66	67,2	68,2	69,1	70	73,1	75,3	77,1	78,5	80,7	82,5
11	59,9	63,1	65,3	67,1	68,5	69,7	70,7	71,6	72,4	75,6	77,8	79,6	81	83,2	85
12	62,2	65,4	67,6	69,3	70,7	71,9	73	73,9	74,7	77,9	80,1	81,8	83,2	85,5	87,2

Tab. 7. Correction to the weight filter A

v [m/s]	2	3	4	5	6	7	8	9	10	11	12
K _A [dB]	-15,0	-11,8	-9,8	-8,4	-7,3	-6,4	-5,7	-5,0	-4,5	-4,0	-3,6

Tab. 8. Relative level expressing the shape of the spectrum L_{rel}

v (m/s)	f (Hz)							
	63	125	250	500	1000	2000	4000	8000
2	-4,5	-6,9	-10,9	-16,7	-24,1	-33,2	-43,9	-56,4
3	-3,9	-5,3	-8,4	-13,1	-19,5	-27,6	-37,4	-48,9
4	-3,9	-4,5	-6,9	-10,9	-16,7	-24,1	-33,2	-43,9
5	-4,0	-4,1	-5,9	-9,4	-14,6	-21,5	-30,0	-40,3
6	-4,2	-3,9	-5,3	-8,4	-13,1	-19,5	-27,6	-37,4
7	-4,5	-3,9	-4,9	-7,5	-11,9	-17,9	-25,7	-35,1
8	-4,9	-3,9	-4,5	-6,9	-10,9	-16,7	-24,1	-33,2
9	-5,2	-3,9	-4,3	-6,4	-10,1	-15,6	-22,7	-31,5
10	-5,5	-4,0	-4,1	-5,9	-9,4	-14,6	-21,5	-30,0
11	-5,9	-4,1	-4,0	-5,6	-8,9	-13,8	-20,4	-28,8
12	-6,2	-4,3	-3,9	-5,3	-8,4	-13,1	-19,5	-27,6

10. Material, finishing

10.1 Material

- Damper bodies are supplied in the design made of galvanized plate without any other surface finishing.
- Damper blades are made of fire resistant asbestos free boards made of mineral fibres.
- Control devices of dampers has cover from mechanically resistant and standing plastic and rest of the parts is galvanised without further surface treatment.
- Springs are galvanized.
- Thermal protective fuses are made of sheet brass, thickness = 0.5 mm.
- Fasteners is galvanized. Fasteners is galvanized

According to the customer's requirements, damper can be made of stainless material.

Specifications for stainless-steel models – classification of stainless steel:

- Class A2 – Food-grade stainless steel (AISI 304 – EN 17240)
- Class A4 – Chemistry-grade stainless steel (AISI 316, 316L – EN 17346, 17349)

The respective stainless steel is the material for all components present or accessing the damper interior; components outside the damper body are typically from galvanised sheet metal (fasteners for mounting the servo drive or mechanics, mechanics components except Item 4), frame components.

The following components, including the fasteners, are made from stainless steel at all times:

- 1) Damper body and all components permanently attached
- 2) Leaf holders, including pins, metal parts of leaf
- 3) Control components inside the damper (leaf angle selector, pin with lever)
- 4) Mechanical components entering the interior of damper body (lower sheet of mechanics, lock holder "1", lock lever "2", lock spring, 8 dia. stopper pin, mechanics pin)
- 5) Inspection hole cover including the clip and fasteners (if they are parts of the cover)
- 6) Bearing for torque transfer from the lever with pin on the angle selector at the leaf (made from AISI 440C)

The leaf of the damper is made from a single piece of homogeneous material Promatect-MST, thickness 30 mm. Plastic, rubber and silicon components, sealants, foaming bands, glass-ceramic seals, housings, brass bearings of the leaf, servo drives, and end switches are identical for all material variants of the dampers.

The thermal link is identical for all material variants of the dampers. Upon specification by customer, the thermal link may be made from A4 from stainless steel sheet metal.

The temperature-dependent initiator of the servo drive (sensor) is modified for stainless-steel variants of the dampers; the standard galvanised screws are replaced with stainless-steel M4 screws of corresponding class the counterpart has stainless-steel riveting M4 nuts.

Some fasteners and components are available in one class of stainless steel; the type will be used in all stainless-steel variants.

The leaf in the variants for chemical environments (Class A4) is always treated with a coating of chemically resistant Promat SR.

Any other requirements for the design shall be considered atypical and shall be addressed on an individual basis.

11. Inspection, testing

The appliance is constructed and preset by the manufacturer, its operation is dependent on proper installation and adjustment.

12. Transportation and storage

12.1 Transport

Dampers are delivered loose. Other packing methods must be agreed with the manufacturer in advance. If packaging is used, they are not subject to return and their price is not included in the product price.

Dampers are transported by box freight vehicles without direct weather impact, there must not occur any sharp shocks and ambient temperature must not exceed +40°C. Dampers must be protected against mechanic damages when transported and manipulated. During transportation, the damper blade must be in the "CLOSED" position.

12.2 Storage


Dampers are stored indoor in environment without any aggressive vapours, gases or dust. Indoor temperature must be in the range from -30°C to +40°C and maximum relative humidity 95 % (avoid condensation on the damper body). Dampers must be protected against mechanic damages when transported and manipulated.

13. Assembly


The damper body should not be deformed in the course of bricking in. Once the damper is built in, its blade should not grind on the damper body during opening or closing.

Fig. 51 Embedding/ fixing the damper

Protecting the damper against buckling, above all when there are big sizes of the fire dampers!



Wrong!



Brace with wooden blocks

To ensure reliable fire damper function it is necessary to avoid blocking the closing mechanism and contact surfaces with collected dust, fibre and sticky materials and solvents..

14. Entry into service and revisions

Before entering the dampers into operation after their assembly and by sequential checks, the following checks must be carried out. Visual inspection of proper damper integration , inside damper area, damper blade, contact surfaces and silicon sealing. Check of thermal protective fuse and closing mechanism. Check the closing function of the damper blade. This can be done by removing of thermal fuse from damper body.

Before entering the dampers with actuating mechanism into operation after their assembly and by sequential checks. Check of blade displacement into the breakdown position "CLOSED" can be done after cutting off the actuating mechanism supply (e.g. by pressing the RESET button at the thermoelectrical starting mechanism BAT or cutting off the supply from ELECTRICAL FIRE SIGNALISATION). Check of blade displacement back into the "OPEN" position can be done after restoration of power supply (e.g. by releasing the RESET button or restoration of supply from ELECTRICAL FIRE SIGNALISATION). Without power supply, the damper can be operated manually and fixed in any required position. Release of the locking mechanism can be achieved manually or automatically by applying the supply voltage.

All effective safety standards and directives must be observed during fire damper assembly.

It is recommended to provide periodical checks, maintenance and service actions on Fire Equipment by Authorized persons. The authorized persons can be trained by Producer, or by authorized Distributor.

For regular or exceptional inspection of interior of fire damper, micro-camera device can be used. On each fire damper is inspection hole. In the case of inspection by camera, take out the black rubber cap, insert the camera inside the damper, check interior and at the end of inspection, put the rubber cap back tightly to cover the empty hole.

14.1 For dampers with mechanical control (designs .01, .11 ja .80) the following checks must be carried out:

Check of closing device and thermal fuse.

To check the function of mechanism, follow these steps:

- Move the damper blade to "CLOSED" position as follows:
 - The damper is in "OPEN" position.
 - Press the control button of the mechanism to move the damper to "CLOSED" position.
 - Check the damper blade shift to "CLOSED" position.
 - Damper closing shall be sharp, the control lever shall be in „CLOSED“ position..
- Move the damper blade to "OPEN" position as follows:
 - Turn the control lever by 90°.
 - The lever will automatically lock in "OPEN" position.
 - Check the damper blade shift to "OPEN" position.
- Check of function and condition of the thermal fuse:
 - To check the function and the status of the fuse is possible to remove whole mechanism from the body of fire damper - mechanism is attached to the dampers body with four screws M6.
 - Removing the thermal fuse from the fuse holder of initiation device, check its correct functionality.
 - The mechanism is identified as M1 to M4, depending on the closing spring strength.

Before entering the dampers with actuating mechanism into operation after their assembly and by sequential checks and following checks must be carried out.

Check of blade displacement into the breakdown position "CLOSED" can be done after cutting off the actuating mechanism supply (e.g. by pressing the RESET button at the thermoelectrical starting mechanism BAT or cutting off the supply from ELECTRICAL FIRE SIGNALISATION). Check of blade displacement back into the "OPEN" position can be done after restoration of power supply (e.g. By releasing the RESET button or restoration of supply from ELECTRICAL FIRE SIGNALISATION).

Manual operation

Without power supply, the damper can be operated manually and fixed in any required position. Release of the locking mechanism can be achieved manually or automatically by applying the supply voltage.

It is recommended to provide periodical checks, maintenance and service actions on Fire Equipment by Authorized persons schooled by Producer.

All effective safety standards and directives must be observed during fire damper assembly.

Dampers could be displaced into position "CLOSED" only in case that ventilator, or Air Handling Unit is switched off. The goal is the securing of proper closing and safe function of Fire Damper in case of Fire.

15. Spare parts

- Spare parts are supplied only on basis of an order.
- Control for square damper and round damper is identical.

16. Restore function of actuating mechanism after fuses initiation

- If fuse Tf1 is initiated (duct outside temperature) than is necessary to change thermoelectrical starting mechanism BAT72B-S. Whereas is initiation temperature higher than actuator mechanism operating temperature +50°C, recommended actuating mechanism manufacturer make complete revision or change actuating mechanism and thermoelectrical starting mechanism.
- If fuses Tf2/Tf3 are initiated (duct inside temperature) than is possible change only part ZBAT72 or ZBAT95 (according initiating temperature).

17. Ordering key

17.1 Fire damper

	FDMB	A x B	.40
Type —			
Nominal size —			
Design —			

Example: FDMB 800x400 .40

If installation holders, installation frame or design for installation in Weichschott system are requested, it has to be mentioned separately in the order. Installation frame could be fixed to the damper body or supplied separately.

17.2 Damper design

.01	- Manual and thermal
.02	- Manual and thermal (Zone 1,2)
.40	- With actuating mechanism BF 230-TN (BFL, BFN 230-T) - voltage AC 230 V
.50	- With actuating mechanism BF 24-TN (BFL, BFN 24-T) - voltage AC/DC 24 V
.80	- Manual and thermal with two terminal switches („OPEN“, „CLOSED“)
.81	- Manual and thermal with two terminal switches („OPEN“, „CLOSED“) (Zone 1,2)


Some designs are possible to supply with optical smoke detector ORS 142 K. For more information contact manufacturer.

17.3 Reinforcement - damper placement outside wall or ceiling construction

Type _____ VRM _____ A x B _____
Nominal size _____

Example: VRM 800x400

17.4 Data label is placed on the damper body.





ETS NORD AS

Address: Peterburi tee 53
11415 Tallinn
Estonia

Phone: +372 680 7360
info@etsnord.ee
www.etsnord.ee

ETS NORD Finland

Address: Pakkasraitti 4
04360 Tuusula
Finland

Phone: +358 0401 842 842
info@etsnord.fi
www.etsnord.fi

ETS NORD Sweden

Address: Järsgjögatan 7
69235 Kumla
Sweden

Phone: +46 70 780 50 26
info@etsnord.se
www.etsnord.se

ETS NORD International

info@etsnord.com
www.etsnord.com



Let's move the air together!